

В		۲		
				4
etric view	al attach	3 ment 2		3
e: 1:1 they snap into place. to PCB. Inspect that the positioning they are securely attached. to be attached with DIN 7985 M3 nuts				2
Oy ankatu 10 4240 SALO Dd E RENTINA-2x2-0 assembly UMBER - VEIGHT - SHEET 1/1				1
В		A		