Effective November 2019 Superseds May 2017



Fuse Accessory Selection Guide









	Fuse Family	Size	PCB Fuse Clip	PCB Mount Holder	Panel Mount Holder	In-Line Fuse Holder	Fuse Block
= =	ABC AGC	1/4" x 1 1/4"	1Axxxx	HBH-I HBV-I	HTB HK HKP HMR HGA-C	HRK HHB HFA HHK HHN HFB	<u>S-8000</u>
100	AGA	1/4" x 5/8"	1Axxxx	-	-	-	-
	AGW	1/4" x 7/8"	1Axxxx	-	-	HRK HHB	-
	<u>AGX</u>	1/4" x 1"	<u>1Axxxx</u>	-	<u>HJL</u>	HRK HHB	3828-1
	<u>ATC</u>	Auto Blade Fuse	1A5600 1A5780	-	-	<u>HHF-JFCU</u>	-
	<u>ATM</u>	Auto Blade Fuse	1A5778 1A5779	-	-	HHM	-
\$1.902,3070	<u>C519</u>	5 mm x 15 mm	1Axxxx	-	-	<u>HHT</u>	
	<u>C520</u>	5 mm x 15 mm	1Axxxx	-	-	HHT	
	FNM FNQ	13/32" x 1 1/2"	<u>1A3400</u>	-	<u>HPG</u>	<u>HEB</u>	<u>BMM603</u>
	FNQ-R KTK-R LP-CC	13/32" x 1 1/2"	<u>1A3400</u>	-	<u>HPG</u>	-	BCM603
	<u>FWH/5</u>	1/4" x 1 1/4"	<u>1Axxxx</u>	HBH-I HBV-I	-	-	<u>S-8000</u>
	GBA GLD	1/4" x 1 1/4"	<u>1Axxxx</u>	-	HLD HK	-	<u>S-8000</u>
	<u>GBB</u>	1/4" x 1 1/4"	<u>1Axxxx</u>	HBH-I HBV-I	HTB HK HKP HMR HGA-C	HRK HHB HFA HHK HHN HFB	<u>S-8000</u>
	GDA GDB GDC	5 mm x 20 mm	1Axxxx HTC-2xxM	<u>H15</u> <u>HBH-M</u> <u>HBV-M</u>	<u>HTB</u>	HHT	HTC-15M HTC-60M
	<u>GMA</u>	5 mm x 20 mm	1Axxxx HTC-2xxM	H15 HBH-M HBV-M	<u>HTB</u>	<u>HHT</u>	HTC-15M HTC-60M
	<u>GMC</u>	5 mm x 20 mm	1Axxxx HTC-2xxM	H15 HBH-M HBV-M	<u>HTB</u>	HHT	HTC-15M HTC-60M
	<u>GMD</u>	5 mm x 20 mm	1Axxxx HTC-2xxM	H15 HBH-M HBV-M	<u>HTB</u>	HHT	HTC-15M HTC-60M



	Fuse Family	Size	PCB Fuse Clip	PCB Mount Holder	Panel Mount Holder	In-Line Fuse Holder	Fuse Block
	KLM KTK	13/32" x 1 1/2"	1A3400	-	HPG	HEB	BMM603
= =	MDA MDL MDQ	1/4" x 1 1/4"	1Axxxx	HBH-I HBV-I	HTB HK HKP HMR HGA-C	HRK HHB HFA HHK HHN HFB	<u>S-8000</u>
BUSS MOH.	MDH	1/4" x 1 1/4"	1Axxxx	HBH-I HBV-I	HTB HK HKP HMR HGA-C	HRK HHB HFA HHK HHN HFB	<u>S-8000</u>
	PCTron	-	=	<u>PCS</u>	-	-	-
	<u>\$500</u> <u>\$501</u>	5 mm x 20 mm	1Axxxx HTC-2xxM	<u>H15</u> HBH-M HBV-M	<u>HTB</u>	<u>HHT</u>	HTC-15M HTC-60M
===	<u>\$505</u> <u>\$506</u>	5 mm x 20 mm	1Axxxx HTC-2xxM	<u>H15</u> HBH-M HBV-M	<u>HTB</u>	HHT	HTC-15M HTC-60M
	SC-1 to 15A	13/32" x 1.31"	1A3400	-	HPS-EE	HEG	<u>BG3011PQ</u>
	<u>SC-20A</u>	13/32" x 1.41"	1A3400	-	HPS-JJ	<u>HEH</u>	<u>BG3011PQ</u>
	SC-25 to 30A	13/32" x 1.62"	1A3400	-	HPS-FF	HEC	BG3011PQ
	SC-35 to 60A	13/32" x 2 1/4"	1A3400	-	-	HEJ	G30060-1CR
	<u>SFE</u>	1/4" x various lengths (5/8" to 1 7/16")	<u>1Axxxx</u>	-	-	HR/HM	-
-	<u>SR-5 / SR-5F / SR-5H</u> <u>SS-5 / SS-5F / SR-5H</u>	-	-	<u>PCS</u>	-	-	-
	TDC10/11	1/4" x 1 1/4"	1Axxxx	HBH-I HBV-I	HTB HK HKP HMR HGA-C	HRK HHB HFA HHK HHN HFB	<u>S-8000</u>
Bussmann	TDC180 TDC600	1/4" x 1"	<u>1Axxxx</u>	-	HJL HJM	HRK HHB	3828-1
3(4)).	<u>TCP70</u>	1/4" x 1"	<u>1Axxxx</u>	-	HJL HJM	HRK HHB	3828-1

Tools & resources

- <u>Webpage</u>
- Parametric search tool
- How to select a fuse holder white paper

Eaton Electronics Division 1000 Eaton Boulevard Cleveland, OH 44122 United States www.eaton.com/electronics

© 2019 Eaton All Rights Reserved Printed in USA Publication No. 10575 BU-MC16086 November 2019

