


## Jack Module Blockout Device

The *PANDUIT* Jack Module Blockout Device provides a simple and secure method to control access to data and deter vandalism to jacks. The Jack Module Blockout Device saves time and money associated with downtime, data security breaches, hardware replacement and infrastructure repair. The innovative design snaps into RJ45 jacks and is released with the special removal tool, ensuring the safety and security of your network infrastructure.



### Key Features

### Benefits

<b>Tamper-resistant</b>	Device blocks unauthorized access to jacks and potentially harmful foreign objects, saving time and money associated with data security breaches, network downtime, repair and hardware replacement
<b>Versatile functionality</b>	Compatible with most RJ45 jacks to accommodate a variety of applications and does not interfere with jack contacts
<b>Compact, low profile design</b>	Device can be installed or removed without interfering with adjacent jacks or hardware
<b>Special removal tool</b>	Device may only be released with the special removal tool, ensuring the safety and security of your network infrastructure

### Installation and Removal Instructions



To install: snap the blockout device into the jack module



To release: insert the special removal tool which attaches to the blockout device



To remove: retract the device

### Ordering Information

Part Number	Description	Color	Std. Pkg. Qty.	Std. Ctn. Qty.
PSL-DCJB	Package of 10 jack module blockout devices and 1 removal tool.	Red	1	10
PSL-DCJB-C	Package of 100 jack module blockout devices and 5 removal tools.	Red	1	10
PSL-DCJB-**	Package of 10 jack module blockout devices and 1 removal tool.	‡	1	10



‡For colors, replace \*\* in part number with BL (black), BU (blue), IW (International white) or YL (yellow).

# Jack Module Blockout Device

## Related Products

PANDUIT provides a wide variety of infrastructure solutions. The roadmap below shows applications for the Jack Module Blockout Device.



1




Faceplates

3



Computer Data Jacks

5



Patch Panels

2



Surface Mount Boxes

4



Zone Cable Boxes

### WORLDWIDE SUBSIDIARIES AND SALES OFFICES

PANDUIT CANADA  
Markham, Ontario  
cs-cdn@panduit.com  
Phone: 800.777.3300

PANDUIT EUROPE LTD.  
London, UK  
cs-emea@panduit.com  
Phone: 44.20.8601.7200

PANDUIT SINGAPORE PTE. LTD.  
Republic of Singapore  
cs-ap@panduit.com  
Phone: 65.6379.6700

PANDUIT JAPAN  
Tokyo, Japan  
cs-japan@panduit.com  
Phone: 81.3.3767.7011

PANDUIT LATIN AMERICA  
Jalisco, Mexico  
cs-la@panduit.com  
Phone: 52.333.666.2501

PANDUIT AUSTRALIA PTY. LTD.  
Victoria, Australia  
cs-aus@panduit.com  
Phone: 61.3.9794.9020

For a copy of PANDUIT product warranties, log on to [www.panduit.com/warranty](http://www.panduit.com/warranty)



For more information  
Visit us at [www.panduit.com](http://www.panduit.com)  
Contact Customer Service by email: [cs@panduit.com](mailto:cs@panduit.com)  
or by phone: 800-777-3300 and reference idcb25

©2005 PANDUIT Corp.  
ALL RIGHTS RESERVED.  
Printed in the U.S.A.  
Product Bulletin Number SA-IDCB25  
12/2005