


**Between Series Adapters (Continued)**


**Jack-Jack (Continued)**

**TNC Flange Mount Jack – SMA Jack**




**Part No. 1057841-1**  
M/A-COM Model No. 3180-2242-00

**SMA Jack – TNC Bulkhead Jack**




**Part No. 1057908-1**  
M/A-COM Model No. 3184-2240-00

**SMB Jack – SMA Jack**




**Part No. 1060487-1**  
M/A-COM Model No. 5180-2240-00

**SMA Jack – OSMP Jack**




**Part No. 1056702-1**  
M/A-COM Model No. 2980-2240-00

**SMA Jack – SSMT or OSMT Jack**




**Part No. 1055694-1**  
M/A-COM Model No. 2380-2240-00

**OSP Jack – SMA Bulkhead Jack**




**Part No. 1059733-1**  
M/A-COM Model No. 4584-2244-02

**SMA 18 GHz Jack – N Series Jack**




**Part No. 1058651-1**  
M/A-COM Model No. 3680-2240-00

**SMA 18 GHz Jack – N Series Flange Mount Jack**




**Part No. 1058653-1**  
M/A-COM Model No. 3680-2242-00

**SMA 18 GHz Jack – N Series Bulkhead**




**Part No. 1058675-1**  
M/A-COM Model No. 3684-2240-00

**OSP Jack – SMA Jack**




**Part No. 1059707-1**  
M/A-COM Model No. 4580-2240-02

**SMA Jack – OSP Bulkhead Jack**



**Part No. 1059729-1**  
M/A-COM Model No. 4584-2240-02

**OSP Floating Flange Mount Jack – SMA Jack**



**Part No. 1059731-1**  
M/A-COM Model No. 4584-2242-02