


CAUTION: In any plug contact area on either side of Plugboard, use only those holes having pads. Holes without pads may have insufficient clearance to adjacent circuitry and using them could cause shorting.


 = No. 1 DIP
 Pin Position

 Zone Letters A,B,C,
 etc., on Y axis and
 X,Y,Z on X axis
 mark position for
 14- or 16-pin DIP's.


 = No. 1 DIP
 Pin Position

 Zone Letters A,B,C,
 etc., on Y axis and
 X,Y,Z on X axis
 mark position for
 14- or 16-pin DIP's.

3. Before pressing terminals into board, position (rotate) terminals to maximize the clearance between the widest part of the terminal and the nearest adjacent conductor.
 2. Where tin-coated circuitry exists, a small percentage of the holes may have solder blockage. This is usually a light "skin" easily penetrated by component leads. In some cases, a soldering iron may be required.
 1. Intended for use in non-hostile environments up to 200 volts RMS or 300 volts DC.
- NOTES: