
T2 Terminator Tooling



Application Tooling Specification Sheet



Order No. 63912-2100

FEATURES

- It is ideally suited for mid-volume bench operations
- This terminator can be installed in the TM42 and the TM40 press or Base Unit adapter for 3BF press
- Quick punch removal with the push of a button for fast and easy tooling change
- Track adjustment capabilities in the T2 Terminators for improved control of the bell mouth size and cutoff tab length
- T2 Terminator has standardized tooling with the Molex FineAdjust Applicator which will reduce your inventory requirements

SCOPE

Products: 3.50 (.138") Wire-to-Wire Connector, Crimp Pin, 18-24 AWG.


Tarminal	Tarminal	Wire Size			Insulation	Strip Length			
Terminal Series No.	Terminal Order No.			IPC/WHMA-A60 (1)				Terminal (2)	
Series No.		AWG	mm²	mm	ln.	mm	ln.	mm	ln.
	50419-9001	18	0.87	1.65-2.20	.065087	1.40-3.00	.055118	3.0-3.5	.118138
50419		20	0.50						
50419		22	0.35						
		24	0.20						

- (1) To achieve optimum IPC-A620 Class 2 insulation crimps, use this insulation OD.
- (2) Overall insulation OD specification for terminal.

Terminator 63912-2100 should be used for insulation OD 1.40-2.20mm (UL1007 or equivalent)

Terminator 63912-2200 should be used for insulation OD 2.20-3.00mm (UL1015 or equivalent)

DEFINITION OF TERMS



The above terminal drawing is a generic terminal representation. It is not an image of any terminal listed in the scope.

UNCONTROLLED COPY Doc No: ATS-639122100 Release Date: 08-20-11 Page 1 of 6 Revision Date: 08-20-11 Revision: A

CRIMP SPECIFICATION

Terminal Series No.	Bell n	nouth	Cut-off Tak	Maximum (Conductor Brush		
Terminal Series No.	mm	ln.	mm	ln.	mm	ln.	
50419	0.05-0.60	.002024	0.30	.012	0-1.0	0.0039	

	Bend up Bend down		Twist	Roll	Punch Width (Ref)				Seam	
Terminal Series No.	Bellu up	Bella dowli	i wist	Kuli	Cond	Conductor		ation	Seam shall not be	
	Degree		Degree		mm	In	mm	ln	open and no wire allowed	
50419	4	3	3	8	1.70	.067	2.40	.095	out of the crimping area	

After crimping, the crimp profiles should measure the following:

	Wire Size			Insulation				Dull Fares				
Terminal Series No.			Crimp Height		Crimp Width (Ref)		Crimp Height (Ref)		Crimp Width (Ref)		Pull Force Minimum	
	AWG	mm ²	mm	ln.	mm	ln.	mm	ln.	mm	ln.	N	Lb.
50419	18	0.87	1.18-1.28	.046050	1.70	.067	2.90	.114	2.55	.100	88.2	19.8
	20	0.50	1.05-1.15	.041045	1.70	.067	2.80	.110	2.55	.100	58.8	13.2
	22	0.35	0.95-1.04	.037041	1.70	.067	2.70	.106	2.55	.100	39.2	8.8
	24	0.20	0.90-0.99	.035039	1.70	.067	2.70	.106	2.55	.100	29.4	6.6

Tool Qualification Notes:


- 1. Pull Force should be measured with no influence from the insulation crimp.
- 2. The above specifications are guidelines to an optimum crimp.

Doc No: ATS-639122100 **UNCONTROLLED COPY** Page 2 of 6 Release Date: 08-20-11 Revision: A

PARTS LIST

T2 Terminator 63912-2100									
Item	Order No Engineering No. Description								
		Perishable	e Tooling						
	63912-2170	63912-2170	Tool Kit (All "Y" Items)	REF					
1	63457-0082	63457-0082	Conductor Punch	1 Y					
2	63445-1741	63445-1741	Conductor Anvil	1 Y					
3	63454-0129	63454-0129	Insulation Punch	1 Y					
4	63445-2471	63445-2471	Insulation Anvil	1 Y					
5	63443-0002	63443-0002	Front Cut-Off Plunger	1 Y					
6	63443-0012	63443-0012	Front Plunger Retainer	1 Y					
		Other Con	nponents						
7	11-17-0022	1739-21	Hold Down Spring	1					
8	11-18-4083	60707-8	Feed Guide	1					
9	11-24-1067	4996-4	Cut-off Plunger Spring	1					
10	63443-0009	63443-0009	Front Scrap Chute	1					
11	63443-0024	63443-0024	Key	1					
12	63443-0085	63443-0085	Wire Stop L-Bracket	1					
13	63443-0090	63443-0090	Wire Stop	1					
14	63443-0093	63443-0093	Shank	1					
15	63443-1720	63443-1720	19.00mm Height Spacer	1					
16	63443-2216	63443-2216	16.00mm Spacer	1					
17	63443-2301	63443-2301	3.05mm Spacer	1					
18	63443-3101	63443-3101	Front Plunger Striker	1					
19	63443-6010	63443-6010	Rear Cover	1					
20	63443-7112	63443-7112	Terminal Hold Down	1					
		Fra	me						
21	63800-8500	63800-8500	T2 Terminator	1					
		Hard	ware						
22	N/A	N/A	M3 by 6 Long FHCS	1**					
23	N/A	N/A	M3 by 6 Long SHCS	2**					
24	N/A	N/A	M3 by 8 Long SHCS	1**					
25	N/A	N/A	M4 by 6 Long SHCS	2**					
26	N/A	N/A	M4 by 12 Long BHCS	2**					
27	N/A	N/A	M4 by 14 Long SHCS	2**					
28	N/A	N/A	M4 by 50 Long SHCS	2**					
29	N/A	N/A	M5 by 12 Long SHCS	1**					
30	N/A	N/A	#10-32 by 3/8"Long BHCS	1**					
** Ava	** Available from an industrial supply company such as MSC (1-800-645-7270).								

UNCONTROLLED COPY Doc No: ATS-639122100 Page 3 of 6 Release Date: 08-20-11 Revision: A




Doc No: ATS-639122100 Revision: A Release Date: 08-20-11 Revision Date: 08-20-11

NOTES

Depending on the press vintage a feed finger assembly is supplied with the T2 Terminator.

- 1. To remove the existing feed finger assembly loosens the M4 x 10 mm set screw in the feed lever.
- 2. Select T2 Feed finger assembly from Terminator box.
- 3. Insert a screwdriver into the slot behind the feed lever and force the feed arm spring to the right.
- 4. Slide the T2 feed finger shaft for TM42 (11-40-5307) or (11-40-0123) for TM40 /Base Unit into the feed lever and to the left of the feed arm spring.
- 5. Release the feed arm spring.
- 6. Position feed finger for selected product. (Refer to Figure 5.1 in the T2 Manual).



UNCONTROLLED COPY Doc No: ATS-639122100 Release Date: 08-20-11 Page 5 of 6 Revision Date: 08-20-11

Revision: A

NOTES

- 1. Molex recommends an extra perishable tooling kit be maintained at your facility.
- 2. Verify tooling alignment by manually cycling the press before crimping under power. Check that all screws are tight.
- 3. Slugs, Terminals, Dirt and Oil should be kept clear of work area.
- 4. This Terminator should be only used in a Molex TM42, TM40, or 3BF Press with a Base Unit adaptor.
- 5. Wear safety glasses at all times.
- 6. For recommended maintenance refer to the TM40, TM42 Manual.

CAUTION: To prevent injury never operate this Terminator without the guards supplied with the press in place. Reference the TM42 press manufacturer's instruction manual.

CAUTION: Molex crimp specifications are valid only when used with Molex terminals, applicators and tooling.

http://www.molex.com

Doc No: ATS-639122100 Release Date: 08-20-11 **UNCONTROLLED COPY** Page 6 of 6 Revision: A Revision Date: 08-20-11